



Barefoot International & Fly High Mfg.
3879 North Richards Street
Milwaukee, WI 53212



Phone: 414-964-3668
Fax: 414-964-5767
E-Mail: orders@fatsac.com
Web: www.fatsac.com

Easy Footer Instruction

- Before starting, the Easy Footer has to be positioned correctly to work well.
- Hang the Easy Footer next to the inside cable on the boom, not at the end of the boom.
- The handle should be 1-2 inches off the water while the person is sitting in the Easy Footer. To adjust the height of the handle, shift the weight in the boat by moving people around.
- If you are unable to appropriately adjust the level of the handle, you may have to adjust the boom clamp up or down the pylon.
- Once everything is positioned correctly tell everyone in the boat to stay put even if they are getting sprayed from the person in the Easy Footer.
- Pull the person at 10-20 mph and when the boat planes out, they will be able to get in a good barefooting position.
- You should never exceed 25 mph while using this product.
- You will be ready to use the boom without the Easy Footer when you can achieve a good foot glide without catching your feet in the water.

